



1/4" X 20
THREADED HOLE

USE 3/8" ANCHOR 201720
TO ATTACH FLOOR PLATE
TO FLOOR. DRILL 3/8" HOLE INTO
FLOOR. USING PROPER TOOL
TIGHTEN 3-5 TURNS AFTER
FINGER TIGHT.



1. LINE UP UMBRELLA STAND DIRECTLY UNDER THE UMBRELLA HOLE IN THE TABLE TOP
2. BOLT DOWN UMBRELLA STAND AS SHOWN
3. INSERT UMBRELLA INTO STAND AND SECURE UMBRELLA INTO STAND WITH 1/4"-20 SET-SCREW IN THREADED HOLE OF STAND TUBE



4660 136th Ave Holland, MI
49424-0452

This drawing contains proprietary information, is the property of CHland may not be reproduced or distributed without the expressed written permission of CHI.

REVISION	DESCRIPTION	DATE	DESCRIPTION: UMBRELLA STAND INSTALL INSTRUCTIONS		
			MATERIAL: -	DRAWN BY: TA	DATE:
			PROGRAM: -	CHECKED BY: -	
			PROGRAM LOCATION: I/CNC PROGRAMS/	SCALE: DO NOT SCALE	
			TOLERANCE: .XX +/- .031, .XXX +/- .015	COPYRIGHT © BY CHARTERHOUSE INC. - ALL RIGHTS RESERVED	DRAWING NAME: -